

DIALOG(R)File 351:Derwent WPI  
(c) 2005 Thomson Derwent. All rts. reserv.

016274872 \*\*Image available\*\*

WPI Acc No: 2004-432767/200441

XRAM Acc No: C04-162218

Continuous recovery of tartaric acid from tartrate-containing materials, especially waste products from wine making, includes decantation before microfiltration

Patent Assignee: LURGI AG (LURG-N); BONSCH R (BONS-I); ERB K (ERBK-I);  
STEIN D (STEI-I)

Inventor: BOENSCH R; ERB K; STEIN D; BONSCH R

Number of Countries: 032 Number of Patents: 003

Patent Family:

Patent No	Kind	Date	Applicat No	Kind	Date	Week
DE 10308045	B3	20040617	DE 10308045	A	20030226	200441 B
EP 1454894	A1	20040908	EP 2004686	A	20040115	200459
US 20040232078	A1	20041125	US 2004789704	A	20040226	200478

Priority Applications (No Type Date): DE 10308045 A 20030226

Patent Details:

Patent No	Kind	Lan	Pg	Main IPC	Filing Notes
-----------	------	-----	----	----------	--------------

DE 10308045	B3		5	C07C-051/42	
-------------	----	--	---	-------------	--

EP 1454894	A1	G		C07C-051/02	
------------	----	---	--	-------------	--

Designated States (Regional): AL AT BE BG CH CY CZ DE DK EE ES FI FR GB

GR HU IE IT LI LT LU LV MC MK NL PT RO SE SI SK TR

US 20040232078	A1			B01D-061/00	
----------------	----	--	--	-------------	--

Abstract (Basic): DE 10308045 B3

NOVELTY - Continuous recovery of tartaric acid from material containing at least 5 wt.% potassium hydrogen tartrate comprises suspending material in water, decanting the suspension, subjecting the clarified liquid to microfiltration, cooling the filtrate under vacuum, centrifuging the potassium hydrogen tartrate crystals, dissolving the crystals in water, removing potassium from the solution by ion exchange, and evaporating the solution to form tartaric acid crystals.

DETAILED DESCRIPTION - An INDEPENDENT CLAIM is also included for apparatus for carrying out a process as above, comprising a heatable suspension vessel (1) with a stirrer, a decanter (5) with a discharge screw or sieve, a ceramic microfiltration unit (12) with a pore size of 0.05-0.6 micro meters, a crystallizer (15), a centrifuge (19), a heatable tartrate dissolver vessel (22), a cation exchanger (27) and an evaporator (30).

USE - For recovery of tartaric acid from tartrate-containing materials, especially waste products from wine making, e.g. yeast and/or tartar.

ADVANTAGE - Decantation before microfiltration results in a filter cake that does not interfere with filtrate formation.

DESCRIPTION OF DRAWING(S) - The drawing is a flow diagram of the process.

Suspension vessel (1)  
Decanter (5)  
Microfiltration unit (12)  
Crystallizer (15)  
Centrifuge (19)  
Dissolver vessel (22)  
Cation exchanger (27)

Evaporator. (30)

pp; 5 DwgNo 1/1

Technology Focus:

TECHNOLOGY FOCUS - CHEMICAL ENGINEERING - Preferred Process: The potassium hydrogen tartrate is crystallized at 5-15 degrees C and 0.007-0.015 bar. Filtrate from the microfiltration of a tartar solution is added to the filtrate entering the crystallizer. Solids from the decantation and/or microfiltration step and/or mother liquors from the crystallization step are recycled, preferably added to the starting suspension.

Title Terms: CONTINUOUS; RECOVER; TARTARIC; ACID; TARTRATE; CONTAIN;  
MATERIAL; WASTE; PRODUCT; WINE; DECANT

Derwent Class: D16; E17

International Patent Class (Main): B01D-061/00; C07C-051/02; C07C-051/42

International Patent Class (Additional): C07C-051/347; C07C-059/255

File Segment: CPI

Manual Codes (CPI/A-N): D05-E; E10-C02E

Chemical Fragment Codes (M3):

\*01\* H4 H402 H482 H8 J0 J012 J1 J172 M280 M312 M321 M332 M344 M349 M381  
M391 M416 M424 M620 M720 M740 M904 M905 M910 N105 N200 N362 N513  
Q232 R032 R00540-K R00540-P R06055-K R06055-P  
\*02\* A119 A960 C710 H4 H402 H482 H8 J0 J012 J1 J172 M280 M312 M321 M332  
M344 M349 M381 M391 M411 M510 M520 M530 M540 M620 M630 M730 M904  
M905 R06082-K R06082-S

Derwent Registry Numbers: 0540-P; 0540-U; 0540-S

Specific Compound Numbers: R00540-K; R00540-P; R06055-K; R06055-P; R06082-K  
; R06082-S

Key Word Indexing Terms:

\*01\* 2623-0-0-0-CL, PRD 2623-0-5-0-CL, ST